




1. Printer display Messages

If the printer display indicates that a consumable needs to be replaced, replace that item. If your print quality is still poor, continue with the following steps.

2. Troubleshooting

Look at the following pages, if the image defect appears on only one of the following pages, then replace the toner cartridge that corresponds to the page color.

For tandem model printers, please contact Konica Minolta Technical Support. See Additional Help below for information about contacting Konica Minolta Technical Support.



Cyan



Magenta



Yellow



Black

Refer to the consumable reorder label inside the front cover of your printer for ordering information.

3. Additional help

For assistance in determining the cause of your print quality defect goto printer.konicaminolta.com and, select your area and country, or refer to the General Information Guide for Local support information.

